

## Radio/Navigation System Schematics

- Figure 1:** [Radio, Power, Ground, Serial Data, and Subsystem References](#)
- Figure 2:** [Audio Amplifier Power, Ground and Serial Data](#)
- Figure 3:** [Radio Control Power, Ground, Serial Data and Microphone](#)
- Figure 4:** [Antennas](#)
- Figure 5:** [Radio to Audio Amplifier](#)
- Figure 6:** [Speakers \(UQG\)](#)
- Figure 7:** [Speakers \(UQS-LF4\)](#)
- Figure 8:** [Speakers \(UQS+LF4\)](#)
- Figure 9:** [Rear Audio Control Module, and Audio/Video Input Adapter](#)
- Figure 10:** [Active Noise Cancellation](#)